

Group Set: 6 Leisure & Sport

Prog No.	Programme for:-	Prewash	Main wash	Last Spin
1	Standard Wash	30°C	60°C	6 mins Fast spin
2	Delicate Wash & Woollens	30°C	40°C	4 mins Medium spin
3	White Towels & Table Linen with Bleach	40°C	80°C	8 mins Fast spin
4	Towels & Table Linen without Bleach	30°C	40°C	8 mins Fast spin
5	Lightly Soiled Athletic Uniforms	30°C	40°C	6 mins Fast spin
6	Heavily Soiled Athletic Uniforms	30°C	40°C	6 mins Fast spin
7	T Shirts & Socks	50°C	80°C	6 mins Fast spin
8	Floor Mop Heads	30°C	80°C	6 mins Fast spin

For best results ensure machine is fully loaded